

OPERATING INSTRUCTIONS AND PARTS LIST
FOR



Power Bee

ENGINE

MODELS: 70007
70008

Always mention both the Model Number and Serial Number of your engine when ordering parts.

These numbers are found on the identification plate attached to the engine.


THE WEST BEND COMPANY
ENGINE DIVISION: HARTFORD, WISCONSIN

ENG. 103R

4/63

PRINTED IN U.S.A.


STARTER



ILLUS. NO.	PART NO.	QTY.	DESCRIPTION
1	151-146	1	Cover assembly
2	20-35	1	Rewind spring
3	13-15	1	Rotor
4	11-71	2	Friction shoe plate
5	29-2	2	Friction shoe spring
6	11-19	2	Spring retainer plate
7	20-3	1	Brake spring
8	27-3	1	Brake washer
9	27-2	2	Fiber washer
10	16-4	1	Brake lever
11	27-8	1	Brake retainer washer
12	29-3	1	Retainer ring
13	25-9	1	Centering pin
14	140-6	1	Cord
15	114-100	1	Cup and screen assembly
16	A144-14	1	T-handle
17	See Chart	1	Flywheel nut (left hand thread)
17A	See Chart	1	Flywheel nut (right hand thread)
18	See Chart	1	External tooth lockwasher (left hand)
18A	See Chart	1	External tooth lockwasher (right hand)
19	10-24 x 3/8	4	Pan head machine screw w/internal external tooth lockwasher
20	111-71	1	Friction shoe assembly includes: Items 4, 5, 6 and 10.
21	25-55	1	Spiral pin
22	25-7	1	Roll pin
	See Chart	1	Starter assembly complete (right hand) not shown
	See Chart	1	Starter assembly complete (left hand) not shown

MODEL NO.	STARTER COMPLETE	FLYWHEEL NUT	EXTERNAL TOOTH LOCKWASHER
70007	30063 (375-114K)	7/16-20 R.H. thick hex nut	7/16 (Right Hand) (8066)
70008	31063 (375-114LK)	7/16-20 L.H. thick hex nut	7/16 (Left Hand) (8051)

MAGNETO




ILLUS. NO.	PART NO.	QTY.	DESCRIPTION	ILLUS. NO.	PART NO.	QTY.	DESCRIPTION
1	11028	1	Coil wedge spring	16	X11030	1	Breaker point replacement set
2	X11260	1	Coil	17	5900	1	Fixed contact clamp screw
3	11027	1	Connection stud insulator	18	9996	1	Connection stud
4	11025	1	Connection stud insulator	19	See Chart	1	Rotor
5	#6	1	Spring lockwasher	20	K-750	1	Sparkie kit
6	11015	1	Nut	21	30673	1	Lead wire terminal
7	5431F	1	Condenser clamp screw		X11061	1	Terminal connection unit (not shown) (includes items 3, 4, 5, 6, 18)
8	X12508	1	Condenser		30498	1	Shaft key (not shown) (Wico 11092)
9	6318	1	Cam wiper felt		30907	1	Ground lead (not shown)
10	X11060	1	Stator plate (plate and core only)		X11189	1	Stator plate unit complete (not shown)
11	2732841	1	High tension lead (with terminal)		See Chart	1	Magneto complete (not shown)
12	See Chart	1	Breaker cam		11785	1	Ground lead terminal (not shown)
13	11024	1	Breaker box cover spring				
14	30031	1	Breaker box cover gasket (Wico 11019)				
15	30029	1	Breaker box cover (Wico 11018)				


MODEL NO.	REPLACEMENT MAGNETO NO.	ROTOR	BREAKER CAM
70007	27062 (FW 2605)	Y12717	30002 (Wico 11021)
70008	31062 (FW 2639)	Y12341	31002 (Wico 11084)

CARBURETOR

ILLUS. NO.	PART NO.	QTY.	DESCRIPTION
1	2775906-3	1	Carburetor gasket
2	010280	2	* Screw
3	012089	1	Throttle shutter
4			Order 229061 (HL122A) carburetor complete
5	09678	1	Throttle shaft clip
6	0992	1	Lockwasher
7	01974	1	Screw
8	012093	1	Choke shaft and lever
9	09626	1	Choke shutter
10	05454	1	Choke friction pin
11	08805	1	Friction pin spring
12	010165	1	Inlet seat gasket
13	010580	1	* Inlet needle, seat and gasket
14	010513	1	* Inlet control lever
15	010578	1	* Inlet tension spring
16	010588	1	* Channel cup plug
17	02531	1	Welch plug
18	02232	1	Drain screw
19	010775	1	* Throttle shaft return spring
20	010581	1	* Control lever pinion screw
21	012091	1	Throttle shaft and lever
22	011498	1	* Idle adjustment screw
23	011718	1	* Main adjustment screw
24	08793	2	Spring
25	011428	2	Washer
26	011401	1	Seal ring
27	0788	1	* Sprir
28	05095	1	* Idle speed regulating screw
29	012475	1	* Diaphragm
30	012473	1	Diaphragm cover gasket
31	GS-155	1	* Gasket and packing set
32	010526	1	Diaphragm cover
33	RK-445	1	Repair parts kit, includes items marked with *
34	010098	6	Body screw
35	010571	1	* Cover retaining screw
36	010527	1	Strainer cover
37	010529	1	Strainer cover gasket
38	010530	1	* Strainer screen
39	010525	1	Fuel pump body
40	012708	1	* Fuel pump diaphragm
41	010880	1	Fuel pump gasket
	A2770589	1	Throttle shaft arm (not shown)
	229061	1	Carburetor complete (HL122A) not shown



POWER HEAD



PARTS LIST

ILLUS. NO.	PART NO.	QTY.	DESCRIPTION	ILLUS. NO.	PART NO.	QTY.	DESCRIPTION
1	64227	1	Spark plug	23	9025	1	Clamp
2	31410	2	Piston pin lock ring	24	27277	1	Bearing cage gasket
3	7017	1	Piston pin	25	1295	3	Rnd hd. screw, 4-40 x 1/4
4	2760015	1	Piston	26	2770159-1	1	Reed plate gasket
5	A31260	1	Piston ring set	27	A2761158	1	Reed plate
6	A27395-1	1	Identification plate w/screws	28	1238	4	Hex slotted hd. screw w/lock-washer, 1/4-20 x 3/4
7	1500	2	Sheet metal screw, 4 x 1/4	29	19209-2	2	Carburetor stud
8	36634	2	Connecting rod screw	30	1490	2	Hex nut, 1/4-20
9	2A36016-3	1	Connecting rod	31	26161	1	Reed stop
10	A31228	1	Crankpin roller set	32	26160-2	3	Reed
11	31241	1	Crankpin roller cage	33	See chart	1	Fan housing
12	A2727010	1	Cylinder	34	2775595	4	Fan housing washer
13	27279	1	Cylinder exhaust gasket	35	1426	4	Nylok hex hd. screw, 1/4-20 x 1/2
14	129146	1	Seal, drive end	36	1434	6	Pan hd. screw w/lockwasher, 10-24 x 5/8
15	2770410	1	Crankshaft retaining ring	37	See chart	1	Support plate
16	127910-1	1	Ball bearing	38	2703449	1	Ignition shorting contact
17	30410	1	Bearing retaining ring	39	1083	1	Fill. hd. screw w/lockwasher 10-24 x 3/8
18	See chart	1	Crankshaft		30396	1	Decal (not shown)
19	31013	1	Crankshaft bearing, upper		G2725-1	1	Gasket set (not shown)
20	30146	1	Seal, magneto end				
21	1457	2	Rnd. hd. screw w/ext. tooth lockwasher, 1/4-20 x 5/8				
22	9010	1	Lead wire retainer				

MODEL NO.	REPLACEMENT SUPPORT PLATE	FAN HOUSING	CRANKSHAFT
70007	A30038	A30596	A2761018
70008	A31038-2	A31596	A2762018

OPERATING INSTRUCTIONS

FUEL MIXTURE

In a separate, clean container thoroughly mix 1/2 pint SAE No. 30 or No. 40 oil with each gallon of gasoline.

Use regular grade of gasoline. High test, ethyl gasoline is not recommended.

Use any good quality Outboard, 2-cycle, or equivalent motor oil.

Strain the fuel mixture through a fine meshed screen when filling gasoline tank on engine to remove dirt and water if present.

PREPARATION FOR STARTING

1. Fill gasoline tank with fuel mixture prepared per above instructions. Wipe up all spilled gasoline.

2. Open gasoline shut off valve.

3. Move choke lever to closed position.

Note: If engine is warm, it may not require choking.

4. Turn ignition switch "ON".

5. Open the throttle and crank engine.

6. When engine starts, move choke lever to open position.

Note: The normal main adjustment needle settings are approximately one turn open. Occasional readjustment may be required but it is not necessary to readjust for starting except for cold weather starting when it may be necessary to open the high speed adjusting needle an additional 1/2 turn.

TO STOP ENGINE

Moving ignition toggle switch to "OFF" position will stop engine by shorting magneto to ground.

Engines not equipped with toggle switch will have a shorting contact which when depressed will short the spark plug to ground.

CARBURETOR ADJUSTMENT

1. Turn both adjustment needles (diaphragm carburetor) clockwise until completely closed.

CAUTION: Do not force needle tightly closed as the seat may be damaged.

2. Turn both needles counter-clockwise one turn. This is the average setting for proper engine operation.

3. Start engine and allow it to warm up, then, if carburetor setting is too "Lean", engine will not run at full speed and will "Pop", and may stop. Turn main adjustment needle counter-clockwise an eighth of a turn at a time until the engine runs smoothly.

If engine runs at full speed without load, but will not maintain full speed under load, richen the main adjustment needle 1/8 turn.

If carburetor setting is too "Rich", engine will not develop full power but will roll and run unevenly under load. Turn main adjustment needle clockwise an eighth of a turn at a time until the engine runs smoothly.

4. To verify proper idle needle setting, start engine and allow to warm up. If motor surges and runs at uneven speed, turn the idle adjustment needle slowly clockwise up to 1/4 turn. If this aggravates rather than corrects the situation, return to the original setting, then turn the idle adjustment needle slowly counter-clockwise up to 1/4 turn. This should cause the engine to "settle down" and run at a constant speed. If engine fails to accelerate, open idle screw 1/8 turn.

5. If engine runs too fast at idling speed, loosen the idle stop screw a little at a time until desired speed is obtained. To increase idling speed tighten the idle stop screw.

MAGNETO

1. Breaker point gap should be set at .020. Set points with cam follower at highest point of breaker cam.

2. Directional arrow on cam must be UP.

3. For magneto inspection or service, contact your nearest authorized dealer.

4. If magneto stator plate is loosened or removed from the engine for any reason, be sure it is re-installed as follows:

(a) Place stator plate in position.

(b) Install hold down screws, but do not tighten.

(c) Turn stator plate to the mid-range position.

(d) Tighten screws.

(e) Reset breaker points to .020" gap.

This places the stator plate in the position for correct ignition timing.

AIR CLEANER

Under ordinary operating conditions, the air cleaner should be cleaned daily. However, under extremely dirty conditions, more frequent cleaning or brushing off of loose dirt is recommended. To clean the air cleaner:

1. Remove the air cleaner from the carburetor.

2. Wash thoroughly using kerosene, gasoline or other good solvent.

3. Blow or wipe dirt from filter element.

4. Re-install air cleaner.

IMPORTANT: Dirt that enters the engine through the carburetor is one of the greatest causes of engine wear. Therefore, it is very important that the air cleaner be serviced regularly as outlined above.

SPARK PLUG

Check and clean spark plugs regularly. A fouled, dirty, or carboned spark plug causes hard starting and poor engine performance.

Set spark plug gap at .030".

STARTER SCREEN

The screen keeps dirt, etc., from entering the fan housing, and clogging the air cooling passages.

Because this engine is air-cooled, it is necessary to keep this screen clean at all times to permit the unrestricted passage of air into the fan housing.

STORING MOTOR

The following steps should be taken to prepare your engine for storage:

1. Close gasoline shut off valve.

2. Start engine and allow to run until it stops from lack of fuel. This will use up all the fuel in the carburetor and prevent the formation of deposits due to evaporation of fuel.

3. Disconnect fuel line and permit all fuel to drain from the gasoline tank. Replace fuel line.

4. Remove spark plug and pour 1/4 cup of motor oil into cylinder. Replace spark plug.

5. Crank engine two or three times to distribute oil throughout cylinder. This will coat the cylinder walls with oil and prevent rust from forming during the storage period.

CHECK LIST

TROUBLE	CAUSE	WHAT TO DO
1. Engine fails to start.	No fuel in tank or shut-off valve closed. Fuel line or fuel tank screen clogged. Flooded.	Fill tank and open shut-off valve. Clean fuel line and screen. Close carburetor main adjustment needle and crank until engine starts. Then turn needle to 1 turn open. Install new spark plug. Replace lead wire or attach to spark plug.
	Spark plug shorted, fouled or broken. Magneto lead wire shorted, broken or disconnected from spark plug. Magneto inoperative (No spark from lead wire.) Breaker points out of adjustment.	Contact factory or nearest authorized dealer. Reset breaker points to .020" gap.
2. Engine hard to start.	Water in gasoline or stale fuel mixture Too much oil in fuel mixture. Engine over or under choked.	Drain and refill fuel system. Drain and refill with correct mixture. If flooded by over-choking, proceed according to instructions in previous section. If under-choked, move choke lever to closed position and crank two or three times. See "Adjustments" on page 7. Replace gaskets.
	Carburetor out of adjustment. Gasket leaks (carburetor or reed plate gaskets). Weak spark at lead wire. Breaker points out of adjustment	Contact the factory or your nearest authorized dealer. Reset breaker points to .020" gap.
3. Engine misses.	Dirt in fuel line or carburetor. Carburetor improperly adjusted. Spark plug fouled, broken or incorrect gap setting. Weak or intermittent spark at lead wire.	Remove and clean. See "Adjustment" on page 7. Clean or replace spark plug - set gap to .030". Contact factory or nearest authorized dealer. Reset breaker points to .020" gap.
	Breaker points out of adjustment.	
4. Engine lacks power.	Air cleaner clogged. Carburetor out of adjustment. Muffler clogged. Clogged exhaust ports.	Clean air cleaner. See "Adjustments" on page 7. Clean carbon from muffler. Remove muffler, rotate engine until piston is at bottom of cylinder. With a wooden scraper or blunt tool, remove all carbon from exhaust ports. Be careful not to scratch or damage piston or cylinder walls. Blow out loose carbon with compressed air. Start engine and run briefly to remove all carbon, then install muffler and gasket. Contact factory or nearest authorized dealer Reset breaker points to .020" gap.
	Poor compression Breaker points out of adjustment.	
5. Engine overheats	Insufficient oil in fuel mixture. Air flow obstructed.	Mix fuel as shown in starting instructions. Clean flywheel, cylinder fins and screen.
6. Engine noisy or knocking	Loose flywheel. Spark plugs incorrect heat range. Worn bearings, piston rings or cylinder walls Bent fan housing.	Tighten flywheel nut. Replace with plugs specified for engine. Contact factory or nearest authorized dealer Remove fan housing and straighten bent portion.
7. Engine "Stalls" under load.	Carburetor main adjustment too "lean" Engine overheats.	Readjust carb. as shown on page 7. See section No. 5 above.